



Nipple Enlarger Clitoris Enlarger

Instructions for Use

www.pumpersparadise.net

The

Body Images

Vacuum Enlarging System

PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE STARTING YOUR PUMPING SESSION.

The Cylinders are designed to stretch your nipples or clitoris to the level of intensity that you desire. They use our shut-off coupling for connection to the hand pump.

It is easy to apply the vacuum cylinders to your nipples or clitoris. The following suggestions will give you the maximum benefit from your new vacuum enlarging system. Start with a moderate vacuum level and you will soon be building to longer and more powerful sessions.

- 1. Use a good lubricant (ie.Body Images Extra Sensual Love Lube) to achieve a good seal. Apply a generous amount to your area, Any hair under the edge of the cylinders will allow the vacuum to leak. It is helpful to remove hair from the area by shaving or moving the hair away from the cylinder opening.
- 2. Place the cylinder over the nipple or clitoris with the valve at the top screwed in, the button depressed and the tubing coupling inserted into the valve. (It will click and lock in position).
- 3. Squeeze the hand pump gently to apply a moderate vacuum. If the vacuum becomes too strong and painful, release the vacuum slightly by pressing the button on the side of the pump, or unscrewing the valve at the top of the cylinder slightly.

- 4. Once the vacuum is at a comfortable level remove the tube coupling from the shut-off valve by pressing the silver button. The cylinder should now be attached without the pump.
- 5. After approximately 20 minutes remove the cylinders by unscrewing the valve slightly. Repeat no's. 1-4 as Required.
- 6. After use the entire kit can be washed in warm soapy water

The small O' Rings supplied in the bag are for use with the smaller cylinders.



www.pumpersparadise.net